

TECHNICAL DATA

Fluke 1654B Multifunction Installation Tester

Key features

Safer, easier installation testing.

The 1654B Installation Tester verifies the safety of electrical installations in domestic, commercial and industrial applications. It can ensure that fixed wiring is safe and correctly installed to meet the requirements of IEC 60364, HD 384 and all relevant local standards

Faster

- Two measurements at once and a dual display. PEFC/PSC and loop impedance are measured and displayed in parallel, saves you more than 50% of test time compared to other loop testers.
- Additional new high current loop mode. Faster measurements compared to loop tests with non-trip mode for RCD's.
- Unique zero adapter for fast, always reliable and accurate test lead and mains cord compensation.
- Fast voltage measurement between L-N, L-PE and N-PE using the mains cord. No need to change measurement connections.

Safer

- Earth Volt Touchpad detects raised earth voltages 50 V, indicating potential dangerous situations.
- Supplied with the SureGrip[™] test leads and clips which gives the user a comfortable, reliable grip

Easy

- Rotary dial knob indicates clearly which function is selected, all functionalities on one spot and no complex multi level menus.
- Large display with backlight, clear symbols with exceptionally wide viewing angle for easy and safe readings.
- PASS/FAIL indication for RCD test results.
- Variable RCD current mode for customized settings.
- Loop & Line Resistance $m\Omega$ resolution
- Test smooth dc sensitive RCDs (Type B)
- Extended Memory
- Extended documentation mode (UK only)

Rugged & lightweight Withstands a drop of 1 meter.

Compact, lightweight (less than 1.3 kg) and padded neck-strap to free your hands for all day testing.

Complete kit

All 1650 models are equipped with detachable leads that can be replaced in case of damage or loss. A durable hard case will protect your instrument in tough field conditions.

Slim probe design with test button

Keeps your eyes on the panel while probing hard to reach points. This remote probe is powered by the tester so always operable (does not require additional batteries).

Zero Adapter

For easy, always reliable and accurate compensation of test leads and mains cords. This adapter can be used for all different kind of mains plugs as well as test accessories like probes, alligator clips etc.



Product overview: Fluke 1654B Multifunction Installation Tester

Extra functionality, faster testing, and as rugged as ever

The 1654B Installation Tester builds upon the rugged reputation of the earlier 1650 Series, only it's re-designed to meet your need for more productive test tools.

This installation tester offers the following new capabilities:

- Fast high current loop test
- Variable RCD current mode for customized settings
- PASS/FAIL indication for RCD tests
- Select voltage measurement between L-N, L-PE and N-PE
- Zero adapter for easy test lead compensation, available as new accessory and also included with standard scope of supply
- Loop & Line Resistance $m\Omega$ resolution
- Test smooth dc sensitive RCDs (Type B)
- Extended Memory
- Extended documentation mode (UK only)

1650 Series Installation Tester Comparison Chart

Specifications: Fluke 1654B Multifunction Installation Tester

Specifications				
AC Voltage Measurement	Range:		500 V	
	Resolution:		0.1 V	
	Accuracy (50 - 60 Hz)		± (0.8% + 3 digits)	
	Input Impedance		3.3 ΜΩ	
	Overload Protection		660 Vrms	
Continuity Testing	Range (autoranging):	20 Ω	, 200 Ω, 2000 Ω	
	Resolution:	0.01	Ω, 0.1 Ω, 1 Ω	
	Test Current:	> 20	> 200 mA	
	Open Circuit Voltage:	> 4 \	> 4 V	
	Accuracy:	± (1.	± (1.5%+3 digits)	



Test Voltage:	50 - 100 - 250 - 500 - 1000 V		
Test Voltage:	50 V		
Test Current:	1 mA @ 50 kΩ		
Insulation Range:	10 kΩ - 50 мΩ		
Resolution:	0.01 мΩ		
Accuracy:	± (3% + 3 digits)		
Test Voltage:	100 V		
Test Current:	1 mA @ 100 kΩ		
Range/Resolution:	20 ΜΩ/0.01 ΜΩ		
Range/Resolution:	100 ΜΩ/0.1 ΜΩ		
Accuracy:	± (3% + 3 digits)		
Test Voltage:	250 V		
Test Current:	1 mA @ 250 kΩ		
Range/Resolution:	20 ΜΩ/0.01 ΜΩ		
Range/Resolution:	200 ΜΩ/0.1 ΜΩ		
Accuracy:	± (1.5% + 3 digits)		
Test Voltage:	500 V		
Test Current:	1 mA @ 500 kΩ		
Range/Resolution:	20 ΜΩ/0.01 ΜΩ		
Range/Resolution:	200 ΜΩ/0.1 ΜΩ		
Accuracy:	± (1.5% + 3 digits)		
Range/Resolution:	500 MO/1 MO		
Accuracy:	10%		
Test Voltage:	1000 V		
Test Current:	1 mA @ 1 MΩ		
Range/Resolution:	20 ΜΩ/0.01 ΜΩ		
Range/Resolution:	200 ΜΩ/0.1 ΜΩ		
Accuracy:	± (1.5% + 3 digits)		
Range/Resolution:	500 MΩ/1 MΩ		
Accuracy:	10%		
, toouracy.	10.0		
Auto Discharge:	Discharge time constant, 0.5 second for C = 1 µF or less		
Live Circuit Detection:	Inhibits test if terminal voltage > 30 V prior to initiation of test		
Maximum Capacitive Load:	Operable with the 5 µF load		

Insulation Resistance Measurement



Loop Impedance Measurement (High Current Mode and Non-Trip Mode)	Range:			100 - 500 VAC (50/60 Hz)	
	Input connection:			Soft Key selection	
	Loop impedance:			Phase to earth	
	Line in	npedance:		Phase to neutral	
	Limit on consecutive tests:		:	Automatic thermal shutdown after 50 consecutive tests at 10 second intervals (typical)	
	Max. Test Current. High Current and Non-Trip Modes:		urrent and Non-Trip Modes:		
	Maximum Test Current @ 400 V		400 V	20 A sinusoidal for 10 ms	
	Maximum Test Current @ 230 V		230 V	12 A sinusoidal for 10 ms	
	Range/Resolution:			20 Ω/0.01 Ω	
	Range/Resolution:			200 Ω/0.1 Ω	
	Range/Resolution:			2000 Ω/1 Ω	
	Accuracy (no Trip mode):			± (3% + 6 digits)	
	Accuracy (Hi Current mode):		e):	± (2% + 4 digits)	
	Computation:		PFC or PSC determined by dividing measured mains voltage by measured loop (L-PE) resistance or line (L-N) resistance		
	Range:		0 - 25 kA		
PFC, PSC Test	Resolution (I _k < 1000 A): 1		1 A		
	Resolution ($I_k >= 1000 \text{ A}$):		0.1 kA		
	Accuracy: Determined by accuracy o		Determined by accuracy of	f loop resistance and mains voltage measurements.	
RCD Testing ¹	G	General, no delay			
	S	Time delay			
	А	Responds to pulsed signal			
	AC	Responds to AC			
	В	Responds to AC up to 1000 Hz: responds to AC superposed by DC			



	Trip Time Accuracy ±(1		% Reading + 1 digit)	
	Multiplier: x ½		2	
	Current Settings:	10	, 30, 100, 300, 500, 1000 mA	
	Current Accuracy:	+0	% - 10%	
	RCD Type 1: G			
	Measurement Range:	31	0 ms (Europe), 2000 ms (UK)	
	RCD Type 1:	S	S	
	Measurement Range:	51	510 ms (Europe), 2000 ms (UK)	
	Multiplier x 1		l	
	Current Settings:	10	10, 30, 100, 300, 500, 1000 mA	
Tripping Time Test	Current Accuracy:	+1	10% - 0%	
(ΔT)	RCD Type 1:	G		
	Measurement Range:	31	0 ms	
	RCD Type 1:	S		
	Measurement Range:	51	0 ms	
	Multiplier:	x 5		
	Current Settings:		10, 30 mA	
	Current Accuracy:		±10%	
	RCD Type 1:	G		
	Measurement Range:		50 ms	
	RCD Type 1:	-		
	Measurement Range:		160 ms	
	Current Range:		50% - 110% of RCD's rated current	
	Step Size:		10% of I _{∆N}	
Tripping Current (ramp)	Dwell time (Type G): 1		300 ms / step	
	Dwell time (Type S): 1		500 ms / step	
	Trip Current Measurement Accuracy:		±5%	
Earth Resistance Test (R _E) - Fluke 1653B + 1654B	Range/Resolution:		200 Ω/0.1 Ω	
	Accuracy:		±(2% + 5 digits)	
	Range/Resolution:		2000 Ω/1 Ω	
	Accuracy:		±(3.5% + 10 digits)	
	Frequency:		128 Hz	
	Compliance Voltage:		+25 V	



Phase Sequence Indication	Icon:	Icon Phase Se	Icon Phase Sequence indicator is active			
	Display of Phase Sequence	9 :				
	Displays '1-		2-3' in digital display field for correct sequence.			
		Displays '3-2-1	1' for incorrect phase.	correct phase.		
		Dashes in place of a number indicate a valid determination could not be made				
Environmental S	pecifications					
Operating Temper	ature		-10 °C to 40 °C			
Humidity (Without Condensation)			10 to 30 °C:	95%		
			30 to 40 °C:	75%		
Safety Specificat	ions					
Safety Rating EN 61		61010-I CAT III	1010-I CAT III 500V, CAT IV 300V			
Mechanical & Ge	neral Specifications					
Size	(L x W x H):		10 x 25 x 12.5 cm	0 x 25 x 12.5 cm		
Weight	1.3 kg					
Batteries	Type AA:			6		
Warranty	3	3 years				
Battery type	Alkaline supplied, u	Alkaline supplied, usable with 1.2V NiCD or NiMH rechargeable batteries				



Ordering information

Fluke 1654B

Multifunction Installation Tester



Fluke. Keeping your world up and running.®

Fluke Europe B.V.
P.O. Box 1186
5602 BD Eindhoven
The Netherlands
www.fluke.com/en
@2023 Fluke Corporation. All rights reserved.
Data subject to alteration without notice.
11/2023

For more information call: In Middle East/Africa +31 (0)40 267 5100

Modification of this document is not permitted without written permission from Fluke Corporation.