

**TECHNICAL DATA** 

# Fluke 1653B Multifunction Installation Tester



# **Key features**

### Safer, easier installation testing.

The 1653B Installation Tester verifies the safety of electrical installations in domestic, commercial and industrial applications. It can ensure that fixed wiring is safe and correctly installed to meet the requirements of IEC 60364, HD 384 and all relevant local standards.

### **Faster**

- Two measurements at once and a dual display. PEFC/PSC and loop impedance are measured and displayed in parallel, saves you more than 50% of test time compared to other loop testers.
- Additional new high current loop mode. Faster measurements compared to loop tests with non-trip mode for RCD's.
- · Unique zero adapter for fast, always reliable and accurate test lead and mains cord compensation.
- Fast voltage measurement between L-N, L-PE and N-PE using the mains cord. No need to change measurement connections.

#### Safer

- Earth Volt Touchpad detects raised earth voltages 50 V, indicating potential dangerous situations.
- Supplied with the SureGrip™ test leads and clips which gives the user a comfortable, reliable grip

### Easy

• Rotary dial knob indicates clearly which function is selected, all functionalities on one spot and no complex multi level menus.



- Large display with backlight, clear symbols and exceptionally wide viewing angle for easy and safe readings.
- PASS/FAIL indication for RCD test results.
- Variable RCD current mode for customized settings.
- Extended Memory
- Extended documentation mode (UK only)

#### Rugged & lightweight Withstands a drop of 1 meter.

Compact, lightweight (less than 1.3 kg) and padded neck-strap to free your hands for all day testing.

#### Complete kit

All 1650 models are equipped with detachable leads that can be replaced in case of damage or loss. A durable hard case will protect your instrument in tough field conditions.

#### Slim probe design with test button

Keeps your eyes on the panel while probing hard to reach points. This remote probe is powered by the tester so always operable (does not require additional batteries).

#### **Zero Adapter**

For easy, always reliable and accurate compensation of test leads and mains cords. This adapter can be used for all different kind of mains plugs as well as test accessories like probes, alligator clips etc.

# Product overview: Fluke 1653B Multifunction Installation Tester

#### Extra functionality, faster testing, and as rugged as ever

The 1653B Installation Tester builds upon the rugged reputation of the earlier 1650 Series, only it's re-designed to meet your need for more productive test tools.

#### This installation tester offers the following new capabilities:

- Fast high current loop test
- Variable RCD current mode for customized settings
- PASS/FAIL indication for RCD tests
- Select voltage measurement between L-N, L-PE and N-PE
- Zero adapter for easy test lead compensation, available as new accessory and also included with standard scope of supply
- Extended Memory
- Extended documentation mode (UK only)

# Specifications: Fluke 1653B Multifunction Installation Tester

Specifications			
AC Voltage Measurement	Range:	500 V	
	Resolution:	0.1 V	
	Accuracy (50 - 60 Hz)	± (0.8% + 3 digits)	
	Input Impedance	3.3 ΜΩ	
	Overload Protection	660 Vrms	



Continuity Testing	Range (autoranging):	20 Ω, 200 Ω, 2000 Ω
	Resolution:	0.01 Ω, 0.1 Ω, 1 Ω
	Test Current:	> 200 mA
	Open Circuit Voltage:	> 4 V
	Accuracy:	± (1.5%+3 digits)



Test Voltage:	250 - 500 - 1000 V	
Test Voltage:	50 V	
Test Current:	1 mA @ 50 kΩ	
Insulation Range:	10 kΩ - 50 mΩ	
Resolution:	0.01 μΩ	
Accuracy:	± (3% + 3 digits)	
Test Voltage:	100 V	
Test Current:	1 mA @ 100 kΩ	
Range/Resolution:	20 ΜΩ/0.01 ΜΩ	
Range/Resolution:	100 ΜΩ/0.1 ΜΩ	
Accuracy:	± (3% + 3 digits)	
Test Voltage:	250 V	
Test Current:	1 mA @ 250 kΩ	
Range/Resolution:	20 ΜΩ/0.01 ΜΩ	
Range/Resolution:	200 ΜΩ/0.1 ΜΩ	
Accuracy:	± (1.5% + 3 digits)	
Test Voltage:	500 V	
Test Current:	1 mA @ 500 kΩ	
Range/Resolution:	20 ΜΩ/0.01 ΜΩ	
Range/Resolution:	200 ΜΩ/0.1 ΜΩ	
Accuracy:	± (1.5% + 3 digits)	
Range/Resolution:	500 ΜΩ/1 ΜΩ	
Accuracy:	10%	
Test Voltage:	1000 V	
Test Current:	1 mA @ 1 MΩ	
Range/Resolution:	20 ΜΩ/0.01 ΜΩ	
Range/Resolution:	200 ΜΩ/0.1 ΜΩ	
Accuracy:	± (1.5% + 3 digits)	
Range/Resolution:	500 ΜΩ/1 ΜΩ	
Accuracy:	10%	
Auto Discharge:	Discharge time constant, 0.5 second for C = 1 µF or less	

4 Fluke Corporation Fluke 1653B Multifunction Installation Tester

Insulation Resistance Measurement



	Range:			100 - 500 VAC (50/60 Hz)	
Loop Impedance Measurement (High	Input connection:			Soft Key selection	
	Loop impedance:			Phase to earth	
	Line impedance:			Phase to neutral	
	Limit on consecutive tests:		:	Automatic thermal shutdown after 50 consecutive tests at 10 second intervals (typical)	
	Max. Test Current. High Current and Non-Trip Modes:		urrent and Non-Trip Modes:		
	Maximum Test Current @ 400 V		400 V	20 A sinusoidal for 10 ms	
Current Mode and Non-Trip Mode)	Maximum Test Current @ 230 V		230 V	12 A sinusoidal for 10 ms	
	Range/Resolution:			20 Ω/0.01 Ω	
	Range/Resolution:			200 Ω/0.1 Ω	
	Range/Resolution:			2000 Ω/1 Ω	
	Accuracy (no Trip mode):  Accuracy (Hi Current mode):		e):	± (3% + 6 digits) ± (2% + 4 digits)	
	PFC or PSC determined by			y dividing measured mains voltage by measured loop (L-	
	Range: 0 - 25 kA		0 - 25 kA		
PFC, PSC Test	Resolution (I <sub>k</sub> < 1000 A): 1 A		1 A		
	Resolution (I <sub>k</sub> >=	Resolution ( $I_k >= 1000 \text{ A}$ ): 0.1 kA			
	Accuracy: Determined by accuracy o		Determined by accuracy of	f loop resistance and mains voltage measurements.	
RCD Testing <sup>1</sup>	G	Genera	ral, no delay		
	S	Time de	elay		
	А	Respon	Responds to pulsed signal		
	AC	Respon	sponds to AC		



	Trip Time Accuracy	±(	1% Reading + 1 digit)	
	Multiplier: x ½		2	
	Current Settings: 10		, 30, 100, 300, 500, 1000 mA	
	Current Accuracy: +0		9% - 10%	
	RCD Type <sup>1</sup> : G			
	Measurement Range: 3		10 ms (Europe), 2000 ms (UK)	
	RCD Type ¹: S			
	Measurement Range: 510		0 ms (Europe), 2000 ms (UK)	
	Multiplier	X -	1	
			, 30, 100, 300, 500, 1000 mA	
Tripping Time Test	Current Accuracy:	· · · · · · · · · · · · · · · · · · ·		
$(\Delta T)$	RCD Type 1:	G		
	Measurement Range:	31	0 ms	
	RCD Type 1:	S		
	Measurement Range:	51	0 ms	
	AA III E		_	
	Multiplier: x			
	Current Settings:		), 30 mA	
	Current Accuracy: ±1		0%	
	RCD Type 1:	G		
	9		) ms	
	RCD Type <sup>1</sup> : S			
	Measurement Range: 16		50 ms	
	Current Range:		50% - 110% of RCD's rated current	
	Step Size:		10% of I <sub>ΔN</sub>	
Tripping Current (ramp)	Dwell time (Type G): 1		300 ms / step	
(гаптр)	Dwell time (Type S): 1		500 ms / step	
	Trip Current Measurement Accuracy:		±5%	
Earth Resistance Test (R <sub>E</sub> ) - Fluke 1653B + 1654B	Range/Resolution:		200 Ω/0.1 Ω	
	Accuracy:		±(2% + 5 digits)	
	Range/Resolution:		2000 Ω/1 Ω	
	Accuracy:		±(3.5% + 10 digits)	
	Frequency:		128 Hz	
	Compliance Voltage:		+25 V	



Phase Sequence Indication	Icon:	Icon Phase Sequence indicator is active			
	Display of Phase Sequence:				
		Displays '1-2-3' in digital display fiel	d for correct sequence.		
		Displays '3-2-1' for incorrect phase.	isplays '3-2-1' for incorrect phase.		
		Dashes in place of a number indicate a valid determination could not be r			
Environmental S	pecifications				
Operating Temperature		-10 °C	-10 °C to 40 °C		
	. O	10 to 30 °C:	95%		
Humidity (Without Condensation)		30 to 40 °C:	75%		
Safety Specificat	tions				
Safety Rating	EN 6	1010-I CAT III 500V, CAT IV 300V	I CAT III 500V, CAT IV 300V		
Mechanical & Ge	eneral Specifications				
Size	(L x W x H): 10 x 25 x 12.5 cm				
Weight	1.3 kg				
Batteries	Type AA:		6		
Warranty	3 y	3 years			
Battery type	Alkaline supplied, usable with 1.2V NiCD or NiMH rechargeable batteries				



# **Ordering information**



# **FLUKE 1653B**



# $\textbf{Fluke}. \ \textit{Keeping your world up and running}. \\ \textbf{\textcircled{\$}}$

Fluke Europe B.V.
P.O. Box 1186
5602 BD Eindhoven
The Netherlands
www.fluke.com/en
@2023 Fluke Corporation. All rights reserved.
Data subject to alteration without notice.
11/2023

Modification of this document is not permitted without written permission from Fluke Corporation.

For more information call:

In Middle East/Africa

+31 (0)40 267 5100